



STRUMENTO MARINO

STRUMENTOMARINO.IT

User Manual
Japan Miyota 6S10
ref.code SM110 - SM113



BATTERY: SR927W
BATTERY LIFE: 4 YEARS

minutes counter

1/20 second

Button A start/stop

Crown


Button B
reset

regular 60 second hand

Regular Position

Set the date

Set the time



1 2 3



A) SETTING THE TIME

1. Pull the crown out to the third position.
2. Turn the crown to set hour and minute hands.
3. After the time has been set, push the crown back to the regular position (1).

B) SETTING THE DATE

1. Pull the crown up to the second position.
 2. Turn the crown clockwise to set the date.
- *If the date is set between the hours of around 9:00 PM and 1:00 AM the date may not change on the following day.
3. After the date has been set, push the crown back to the regular position (1).

C) USING THE STOPWATCH

This chronograph is able to measure and display time in $1/20$ second united up to maximum of 59min 59 sec. The chronograph $1/20$ second hand keeps continuously for 30 seconds after starting and then stops at Zero position. Stopwatch will stop automatically after running continuously for 31 minutes.



[Measuring time with the stopwatch]

1. Press button “A” to start the stopwatch.
2. The stopwatch can be started and stopped each time button “A” is pressed.
3. Press button “B” to reset the stopwatch and stopwatch minute and second hands return to their [1] positions.

D) CHRONOGRAPH RESET (INCL. AFTER REPLACING BATTERY)

This procedure should be performed when the stopwatch second & minute hand does not return to the [0] position.

1. Pull the crown out to the third position.
2. Press the button “A” once to set the chronograph second hand to the Zero position.

*The chronograph hands can be advanced rapidly by continuously pressing button “A”.

3. Once the hands have been set at Zero position, reset the time and return the crown to its regular position [1].